

MOD 3.666 Addendum

When you replace the OD1 (T2) trimpot don't follow the instruction in the mod 3.666. Just replace the pot, don't replace the resistor R74. I include a 47k pot with the mod3.666 kit in stead of the 500k wich is to high in value. So there's no need to put in a bridgewire.

MJMP